

## Viewing Photographs on CASSIOPEIA


By installing the "Photo Viewer" software recorded on the CASSIOPEIA Software Applications CD-ROM, the CASSIOPEIA BE-300 can display JPEG, GIF, BMP, PNG and other image files.

First follow the instructions at "PC Connect installation and use" to install specialized "PC Connect" software recorded on the CASSIOPEIA Software Applications CD-ROM. Also link the CASSIOPEIA and the computer by connecting the included USB cradle to the computer.  
(This installation and connection only needs to be done one time.)


## Installing the Photo Viewer software onto CASSIOPEIA

This software can be installed only into CASSIOPEIA main memory. Before following the rest of these instructions, close all running applications on the computer.

- (1) Place the CASSIOPEIA on the USB cradle and turn it on. If the CASSIOPEIA is already on when placed on the cradle, leave it on.
- (2) The following PC Connect window will appear on the computer screen.



Wait for the synchronization symbol, shown in the red circle below, to appear on the screen of the CASSIOPEIA.



If the synchronization symbol does not appear after a short period of time, reconnect the USB cable to the USB port on the PC and reconnect the CASSIOPEIA to the cradle.

- (3) Begin installing the Photo Viewer software onto CASSIOPEIA.

Insert the CASSIOPEIA Software Applications CD-ROM into the computer's CD-ROM drive.


This software can be installed only into CASSIOPEIA main memory. It cannot be installed onto a CF card.

- (4) The following window should automatically appear on the computer screen. If the window does not appear after waiting for a short period of time, use File Explorer to view the contents of the CD-ROM and double-click the "menu.exe" file in the file list.


- (5) Click [Software List] in the opened window.




- (6) In the software list, click on "Photo Viewer" to select it, and then click [Install].



- (7) While following the instructions on the screen, the following window will appear. This software can only be installed into CASSIOPEIA main memory, so click [Main]. The software will begin installing to the main memory. To stop installation of the software, click [Cancel].




- (8) When installation is completed, the following window will appear. Click [Exit].




- (9) The Software List window for BE-300 will reappear.

Click [Back] or the [X] in the top right corner of the window to return to the MENU, and then click [Exit] to close the MENU.




## Transferring photo data files to CASSIOPEIA


- (1) On the PC Connect window, click "Settings" and then "Folder Synchronization Settings...", and the Folder Synchronization Settings window will open.



- (2) In the following window, click the "Photo" folder. The "Folder Synchronization Settings (Detail)" window will appear.



- (3) In the window, enter information as explained below. Use the initialized settings in normal circumstances. After completing the settings, click [OK].



- PC Folder : "C:¥CASSIOPEIA¥Photo"

The following steps will result in automatic creation of this folder on the PC.

- CASSIOPEIA Folder : "Nand Disk¥My Documents¥Photo"

Do not change the folder for photographs on CASSIOPEIA under normal circumstances. The initial settings are configured to transfer data to CASSIOPEIA main memory. To transfer photo files to the CF card, change the name in this field from "Nand Disk¥My Documents¥Photo" to "Storage Card/My Documents¥Photo." If a folder other than either of these is set, it will not be possible to display the transferred photo files.

- Control : "Synchronize"


This setting will result in complete matching of all folder contents between the CASSIOPEIA and the PC when performing a synchronization. However, a file deleted for the folder on the PC side will not delete the matching file on the BE-300. To delete BE-300 files, use the Photo Viewer application.

Select the "Import" option to copy files from the PC to CASSIOPEIA, or select "Export" to copy files from CASSIOPEIA to the PC.


- Option: None

When the "SubFolder Sync/Transfer" checkbox is checked, any subfolders present in the designated transfer folder will also be synchronized or copied.


- (4) The "Folder Synchronization Settings" window will reappear. Click the "Photo" checkbox to place a checkmark in it, and then click [OK]. The settings are complete for transferring photograph files.




- (5) Click the [Synchronize] button (shown in the red circle below), and any folders that did not already exist when they were set in Step 3 will be automatically created. (Initial setting --> C:\CASSIOPEIA\Photo)




- (6) Use an application like File Explorer to put photograph data files into the PC folder that was created by Step 5. (Initial setting --> C:\CASSIOPEIA\Photo) Then click the [Synchronize] button again.
- (7) Synchronization will start, and the window shown below will appear.




- (8) When synchronization is complete, the PC Connect window will appear as shown below, and the photo files will have been transferred.




- (9) The files have been prepared for displaying on Photo Viewer.
- (10) At the CASSIOPEIA Top menu, double-tap the "Photo Viewer" application, and the software will start.



- (11) After "Photo Viewer" has started, the transferred photograph files will be displayed in a thumbnail table. Double-tap any photo you want to display at full size.



- (12) By tapping the [Size] button, you can adjust the display format of the photo data files to such options as "Compressed," "Uncompressed," "Zoom," and "Full Screen."



To learn more about using "Photo Viewer" software, see "Chapter 5: Photo/Music Programs" in the "User Guide".